

## Sets for Sony FS7II/FX9



### Basic Set for Sony FS7II/FX9

Consists of:  
 Top Plate for Sony FS7II/ FX9  
 Plate for Sony FS7II/ FX9  
 Lens Adapter Support LAS-1  
 Support Rods 240mm/9.4in, Ø15mm  
 15mm LWS Rod Console

**KK.0035874**

K2.0034691  
 K2.0035830  
 K2.0003899  
 K2.66253.0  
 K2.65264.0

### Pro Set for Sony FS7II/FX9

Consists of:  
 Plate for Sony FS7II/ FX9  
 Top Plate for Sony FS7II/ FX9  
 Lens Adapter Support LAS-1  
 E- to PL-Mount Support for Vocas  
 Side Bracket Right for Sony FS7II/FX9  
 Side Bracket Left for Sony FS7II/FX9  
 Viewfinder Bracket for Sony FS7II/ FX9  
 Camera Center Handle CCH-4  
 Sliding Adapter for CCH-4  
 Rod Mounting Bracket RMB-3  
 15mm Reduction Insert  
 15mm LWS Rod Console  
 Support Rods 240mm/9.4in, Ø15mm

**KK.0035875**

K2.0035830  
 K2.0034691  
 K2.0003899  
 K2.0034700  
 K2.0034709  
 K2.0034727  
 K2.0034657  
 K2.0017270  
 K2.0019282  
 K2.0006186  
 K2.66255.0  
 K2.65264.0  
 K2.66253.0



**Viewfinder Bracket for Sony FS7II/FX9**, K2.0034657



**Plate for Sony FS7II/FX9**, K2.0035830



**Top Plate for Sony FS7II/ FX9**, K2.0034691



**E- to PL-Mount Support for Vocas**, K2.0034700



**Side Bracket Right for Sony FS7II/FX9**, K2.0034709



**Side Bracket Left for Sony FS7II/FX9**, K2.0034727

## Sets for Sony PXW-FS7 / FS7 II



### Basic Set for Sony PXW-FS7 / FS7 II

Consists of:  
 Adapter Plate for Sony PXW-FS7  
 Lens Adapter Support LAS-1  
 Support Rods 240 mm Ø 15mm

**KK.0006716**

K2.0003684  
 K2.0003899  
 K2.66253.0

### Top/Bottom Sony Viewfinder Set for Sony PXW-FS7 / FS7 II

Consists of:  
 Adapter Plate for Sony PXW-FS7  
 Lens Adapter Support LAS-1  
 Support Rods 240 mm Ø 15mm  
 Top Plate for Sony PXW-FS7

**KK.0006717**

K2.0003684  
 K2.0003899  
 K2.66253.0  
 K2.0003722

### Pro Set for Sony PXW-FS7 / FS7 II

Consists of:  
 Adapter Plate for Sony PXW-FS7  
 Lens Adapter Support LAS-1  
 Support Rods 240 mm Ø 15mm  
 Top Plate for Sony PXW-FS7  
 Center Camera Handle, CCH-2  
 Viewfinder Bracket for Sony PXW-FS7  
 15 mm LWS Rod Console  
 Support Rods 140 mm Ø 15mm

**KK.0006718**

K2.0003684  
 K2.0003899  
 K2.66253.0  
 K2.0003722  
 K2.73002.0  
 K2.0003749  
 K2.65264.0  
 K2.66254.0

### Pro Set for Sony PXW-FS7/ FS7 II / BP-8

Consists of:  
 Adapter Plate for Sony PXW-FS7  
 Lens Adapter Support LAS-1  
 Support Rods 240 mm Ø 15mm  
 Top Plate for Sony PXW-FS7  
 Center Camera Handle, CCH-2  
 Viewfinder Bracket for Sony PXW-FS7  
 15 mm LWS Rod Console  
 Support Rods 140 mm Ø 15mm  
 Bridge Plate BP-8 Set (19 mm Rods)

**KK.0006719**

K2.0003684  
 K2.0003899  
 K2.66253.0  
 K2.0003722  
 K2.73002.0  
 K2.0003749  
 K2.65264.0  
 K2.66254.0  
 K2.47090.0

### Pro Set for Sony PXW-FS7/ FS7 II / BP-9

Consists of:  
 Adapter Plate for Sony PXW-FS7  
 Lens Adapter Support LAS-1  
 Support Rods 240 mm Ø 15mm  
 Top Plate for Sony PXW-FS7  
 Center Camera Handle, CCH-2  
 Viewfinder Bracket for Sony PXW-FS7  
 15 mm LWS Rod Console  
 Support Rods 140 mm Ø 15mm  
 Bridge Plate BP-9 Set (15 mm Rods)

**KK.0006720**

K2.0003684  
 K2.0003899  
 K2.66253.0  
 K2.0003722  
 K2.73002.0  
 K2.0003749  
 K2.65264.0  
 K2.66254.0  
 K2.47091.0



**Adapter Plate for Sony PXW-FS7/ FS7 II**, K2.0003684



**Top Plate for Sony PXW-FS7 / FS7 II**, K2.0003722



**Viewfinder Bracket for Sony PXW-FS7/ FS7 II**, K2.0003749



**Lens Adapter Support LAS-1**, K2.0003899

## Sets for Sony Sony a7s II / Sony a7r II\*\*

### Basic Set for Sony a7s II

Consists of:  
 Base Plate for Sony a7s II  
 Lens Adapter Support LAS-1  
 Side Bracket left for Sony a7s II  
 Cable Clamp for Sony a7s II  
 Cage Top Handle CTH-1  
 Support Rods 240 mm (9.4 inch), Ø 15 mm

**KK.0010057**

K2.0009468  
 K2.0003899  
 K2.0009440  
 K2.0009646  
 K2.66227.0  
 K2.66253.0

### Pro Set for Sony a7s II

Consists of:  
 Base Plate for Sony a7s II  
 Lens Adapter Support LAS-1  
 Side Bracket left for Sony a7s II  
 Cable Clamp for Sony a7s II  
 Side Bracket right for Sony a7s II  
 Cage Top Handle CTH-1  
 Support Rods 240 mm (9.4 inch), Ø 15 mm  
 Bridge plate adapter for ALEXA Mini (BPA-4)  
 Bridge Plate Sled, BPS-2  
 Bottom dove-tail plate 300 mm/12 inch  
 Rod mounting bracket (RMB-3)  
 Viewfinder Cross Pipe

**KK.0010079**

K2.0009468  
 K2.0003899  
 K2.0009440  
 K2.0009646  
 K2.0009455  
 K2.66227.0  
 K2.66253.0  
 K2.0006352  
 K2.66260.0  
 K2.0000324  
 K2.0006186  
 K2.0013302



**Base Plate for Sony a7s II**, K2.0009468



**Cable Clamp for Sony a7s II**, K2.0009646



**Side Bracket left for Sony a7s II**, K2.0009440



**Side Bracket right for Sony a7s II**, K2.0009455



**Viewfinder Cross Pipe**, K2.0013302

**\*\* discontinued items  
 no stock available anymore**